


Submersible Drainage Pump

JV 1000



Selection Chart																
Pump Type	Motor	Q = Delivery												PUMP	Weight (kg)	
		l/min	0	10	20	30	40	60	90	140	180	240	300			
			m ³ /h	0	0.6	1.2	1.8	2.4	3.6	5.4	8.4	10.8	14.4	18.0		
		H = Total Head in Meters														
JV 1000	1			10.8	10.6	10.3	10.2	10.0	9.0	7.5	6.0	3.0				8